


REVIVE Pebble Diffuser




USB Ultrasonic Mobile Diffuser


Ultrasonic technology works by transforming water and essential oils into millions of microparticles and dispersing them into the air through an aromatic mist. Essential oil can easily be absorbed by the body this way and the effects can be felt on the mind and body. Your senses will be invigorated!

Specifications

1. Mist Outlet
2. Cover
3. Air Outlet
4. Water Tank
5. Power Button
6. Vent
7. Maximum Water Level Line
8. Power Input
9. USB Cable



Operating Instruction



Specifications

Size	2.8" (d) x 5.5" (h)
Weight	5.3oz
Color	Black
Features	Whisper-quiet Operation Continuous and intermittent mode setting Portable and convenient for travel Auto shut-off function
Rated power	5W max
Adapter power	DC 5V/1A
Water capacity	55ml
Mist output	18ml/h on continuous & 9 ml/h on intermittent
Accessories	1 USB cable,
Coverage	Approx. 200-400 sq ft

Maintenance

To ensure your diffuser continues to operate at peak performance, we recommend that you:

- Empty any residual water and clean the tank before refilling or changing essential oils.
- Always unplug the diffuser from its power source before cleaning.
- Keep water out of the air outlet. During filling and emptying of the tank be cautious to avoid this.
- Only use clean, room temperature water to fill the water tank.
- If there is build up of oil residue on the ceramic disc, clean it using a cotton swab.

Warnings

In the case of abnormal situations such as smoke, peculiar smells or excessive noise, any further use may result in an accident. You should unplug the unit immediately and contact us at hello@revive-eo.com.

Never wrap the unit with a cloth or paper. Doing so interferes with the unit's ability to properly dissipate heat, which may lead to melting or fire.

Never attempt to disassemble or repair the product. In case of internal inspection or repair needed, please contact us at hello@revive-eo.com.

Please keep the product out of the reach of children to avoid injury or electric shock.

Please read the instructions carefully before using.

Troubleshooting

	CAUSE	SOLUTION
Will not turn on	Unit is out of water.	Add up to 55ml of water to the unit.
	Not getting power to the unit.	Check that the USB cable is properly plugged in to the unit and the power source.
No mist or abnormal mist	Unit needs to be cleaned. Oil residue has built up on ceramic disc or sensor.	Clean unit as advised in Maintenance section.
	Water level is higher than max water line.	Remove excess water.
	Using water that is not compatible.	Use only room temperature water. Avoid using water with a high mineral content.
	Blocked air flow/vents.	Ensure the diffuser vents on the base of the unit are not blocked, and move things restricting air flow around the unit.
	Unit may be in intermittent mode if it is diffusing then stopping every 9 seconds.	To change the unit into continuous mode so there is uninterrupted diffusing, push the power button once.
Unit will not stop running when empty	Water level indicator is dirty.	Clean unit as advised in Maintenance section. Pay particular attention to the ceramic disk in the tank.