




Instructions for use:




1. Remove top cover from the main body.




3. Pour water into the Water Tank up to the Max Water Level Marker. Add 15 drops of essential oil directly into the Water Tank.



5. Plug the AC end of the power cord into an electrical wall outlet.



2. Attach the power cord using the socket located on the back of the main body.



4. Replace top cover by aligning onto main body

	Left Button	Right Button
Push	Mist Output	Light
1	High	Bright
2	Low	Dim
3	Off	Off


6. Turn on the diffuser using the left touch button. You can adjust the light with the right touch button.

Care & Maintenance:

Always empty residual water and clean the tank before refilling or changing essential oils. Only use the power cord that is supplied with the unit. Always remove the power cord before cleaning. Essential oil should not come in contact with the exterior surface of the unit.

TO CLEAN:

1. Remove top cover. Empty the water from the water tank away from the air outlet.
2. The ceramic disc, located in the bottom of the water tank, should not come in contact with any hard or sharp objects. To remove possible buildup, gently use a cotton swab dipped in white vinegar to wipe out the inside.
3. Use a damp cloth to wipe clean the unit. For a more deep clean use mild dish soap and water on the damp cloth. Do not use strong cleaning agents and do not submerge unit in water.
4. Dry with a soft cloth to avoid mineral buildup.



Ensure the diffuser is placed on a flat, water-resistant surface while operating.

NOTES: The unit will automatically shut off completely when water level becomes too low. Disconnect adapter from electrical outlet when not in use.

Troubleshooting

	CAUSE	SOLUTION
Will not turn on	Unit is out of water.	Add up to 1200ml of water to the unit.
	Not getting power to the unit.	Check that the cables are properly plugged in to the unit and the power source.
	Oil residue has built up on ceramic disc or sensor	Unit needs to be cleaned. Please clean unit as advised in Maintenance section.
No mist or abnormal mist	Water lever is higher than max water line.	Remove excess water.
	Using water that is not compatible.	Use only room temperature water. Avoid using water with a high mineral content.
	Water lever is lower than minimum water amount.	Add addition water to the tank.
Unit will not stop running when empty.	Water lever indicator is dirty.	Clean unit as advised in Maintenance section. Pay particular attention to the ceramic disc in the tank.

Warning:

In the case of abnormal situations such as smoke, peculiar smells or excessive noise. You should unplug the unit immediately and contact us at hello@revive-eo.com.

Never wrap the unit with a cloth or paper. Doing so interferes with the unit's ability to properly dissipate heat.


Never attempt to disassemble or repair the product. In case of internal inspection or repair needed, please contact us at hello@revive-eo.com.

Please keep the product out of the reach of children. Please read the instructions carefully before using.

Specifications:

Size:	9.9" (d) x 6.1" (h)
Weight:	32oz
Use:	Up to 15 hours
Power Supply:	AC100-240V
Power Consumption:	24V
Water Capacity:	1200mL
Material:	BPA Free Plastic
Mist Functions:	High, low

REVIVE Valencia Diffuser
Ultrasonic Essential Oil Diffuser



The Valencia Ultrasonic Diffuser is a beautiful, large capacity, Ultrasonic diffuser perfect for large rooms and all day diffusing! Ultrasonic vibrations transform water and essential oils into millions of microparticles that are dispersed into the air through an aromatic mist.