



# REVIVE

## Petals Ultrasonic Diffuser



G24

By breaking up the mixture of water and essential oil into millions of micro-particles, a stream of air diffuses the activated ingredients in the essential oil, which can easily be absorbed by the body and freshen the room. By adopting aromatherapy principles, your body will be gradually relaxed and your senses will be invigorated.



### SPECIFICATIONS

- 1.Dimensions: 4.72" x 7.48"/120 x 190mm
- 2.Product Weight: 8.11oz/230g
- 3.Power: Input/Output: AC100-240V 50/60Hz/DC24V/0.5A
- 4.Time Modes: 60mins/120mins/180mins/ON
- 5.Tank Capacity: 200mL
- 6.Coverage: 320 sq ft
- 7.Materials: PP – BPA free
- 8.Method of Mist Production: Ultrasonic vibration at approximately 2.4MHz
- 9.LED Lights: 7 colors

### DIRECTIONS

1. Remove the cover.
2. Connect the plug into the socket on the side of the unit.
3. Add tap water up to the max water level line – 200ml, then add 2-3 drops of your favorite REVIVE essential oil.
4. Replace the top cover. Plug the power cable into the wall and enjoy.

#### NOTES:

- This unit has an anti-dry protection system and will automatically shut off completely when water level becomes too low.
- Disconnect Adapter from electrical outlet when not in use.

### FUNCTIONS

**Mist:** Turns on the mist function of the unit (button on the left). There are three options – Continuous/Intermittent (15 secs on then 15 secs off) and Off.

**Light:** 7 colors of LED lights emitted by the unit (middle button). There are three options – Cycle through all the colors/Lock your favorite color and Off.

**Timer:** Set the amount of time you would like the unit to run for (button on right). "ON" by default: 60 min/120min/180 min and On (Continuous).

### RUN TIME

In **intermittent mode**, the diffuser can run for over 8 hours.


In **continuous mode**, the diffuser can run for over 4 hours.

### MAINTENANCE

After using 5-6 times, or 2-3 days, please clean the unit as follows:

- Unplug the unit from main power source.
- Unplug power cord from base of unit.
- Pour out remaining water from the drain side of the tank.
- Wipe with a soft cloth. Avoid ultrasonic vibration plate area, which can be gently cleaned with a cotton ball.

**Never use other acids, enzymes or detergents, as this may risk poisonous gas to be created or cause malfunction.**



### TROUBLE SHOOTING

Please refer to the below chart in the event the diffuser does not operate properly.

Symptom	Possible Cause	Solution
Will not switch on or switch off early	<ul style="list-style-type: none"><li>● Is there enough water in the tank?</li><li>● Are the power cables connected properly?</li></ul>	<ul style="list-style-type: none"><li>● Add water to the tank.</li><li>● Disconnect, check cables, reconnect and try again.</li></ul>
No mist or abnormal mist	<ul style="list-style-type: none"><li>● Not enough water?</li><li>● Too much water?</li><li>● Dirt on the ultrasonic plate?</li><li>● Inner shell and outer shell are not installed properly?</li><li>● Dirt on the air suction port on the underside of the base?</li></ul>	<ul style="list-style-type: none"><li>● Add amount of water in the tank.</li><li>● Water must never be filled over 200 ML (MAX) line.</li><li>● Please refer to maintenance instructions, remove or reinstall correctly, so vapors can be released freely.</li><li>● Clean the air suction port .</li><li>● Reduce airflow will affect mist.</li></ul>

For any other issues, please contact [hello@revive-eo.com](mailto:hello@revive-eo.com).